



Quick commissioning of ULYS FLEX MODBUS



When you power up the meter for the first time, the following pages are displayed in succession.



To define the preliminary configuration, press the SET button for at least 3 sec.

- 1 Select the wiring mode

 Press or
 The mode will flash.
 Available values:
 3.4.3=3-phase, 4 wires, 3 currents
 3.3.2=3-phase, 3 wires, 2 currents
 1ph=single phase
 Change the mode using or Confirm with
- 2 Enter the required FSA

 Appuyer 2 fois sur
 Press
 The value will flash.
 Available values:
 500 A / 4 kA / 20kA
 Modify the value using or Confirm with

The FSA corresponds to the current caliber
 For $I \leq 500$ A, choose the 500 A caliber
 For $500 \text{ A} \leq I \leq 4 \text{ kA}$, choose the 4 kA caliber
 For $4 \text{ kA} \leq I \leq 20 \text{ kA}$, choose the 20kA caliber
- 3 Sauvegarder et quitter
 For 3 sec press

 Confirm with



Confirm with

